# NEOLITH

## RECOMMENED TOOLS FOR MACHINING COUNTERTOPS

In order of usage:

#### 1. Blades

a) Continous rim, electroplated diamond cutting disc. Inside 60 mm diameter;

Outside (mm and RPM): • 300 mm: 2.500 RPM

350 mm: 2.200 RPM400 mm: 1.900 RPM

• Straight Advance speed: 1,3 m/min

• Mitre Advance speed: 1m/min



b) Segmented blade for porcelain. Recommended speed:

- 300 mm: 2.500 RPM Ref. 720-172
- 350 mm: 2.200 RPM Ref. 720-174
- 400 mm: 1.900 RPM Ref. 720-176
- Straight Advance Speed: 1,3 m/min
- Mitre Advance speed: 1 m/min



## 2. Electroplated diamond grinding disc, type G100 and G30

Refining and trimming edges. Recommended speed 2.000 RPM.



#### 3. Beveling and pre-grinding edges

Cup wheels, medium, grain 60. Recommended speed 2.000 RPM TheSize recommends cup wheels from Tyrolit

Ref: 720-061



#### 4. Glue, putty and pigments

Putty "Soldapiedra" for countertops and Interior applications. Color matching pigments available

Ref: Depending on the colors



#### 5. Silicon carbide discs

Silicon Carbide velcro discs for dry use. Grit 60, 120, 220, 400. Recommended speed 2.000 RPM Ref: Depending on diameters and grits











TheSize Sintered Ceramics SL info@thesize.es www.neolith.com

# NEOLITH

## RECOMMENED TOOLS FOR MACHINING COUNTERTOPS

#### 5. Silicon carbide discs

Silicon Carbide velcro discs for wet use.



#### 7. Felt pad

Ø 125 Ref. 720-181 Ø 180 Ref. 720-064



#### 8. Core drill 20-35 mm

Electroplated diamond, cutting drill bits. Ø 35 Ref. 411-018



#### 9. Drill bits 6-12 mm

Electroplated diamond, cutting drill bits.

Use the drill without the hammer action. Use water for cooling.

Ø 6 Ref. 853-099

Ø 8 Ref. 853-098



#### 10. 4" Diamond blade

Segmented blade for porcelain. Recommended speed: 11.000 RPM. (Supplied from TheSize)

Ref. 720-164



### 11 Continous rim porcelain blade

Ref. 411-009



### 12. 4" Angle grinder and 7" Buffer













## RECOMMENED TOOLS FOR MACHINING COUNTERTOPS

Special tools for CNC machining:

#### 13.a Finger bit

Recommended speed 4.600 RPM. 120 mm/min Ref. 720-107



#### 13.b Core drill

Recommended speed 4.500 RPM. 20 mm/min Ref. 720-165



For CNC polishing, the tools are the same than the used for quarz and granites.







